


**MICROTEC®**

## Manual TinyBL 2.2

**Caution:** Make sure you do this procedure with stable and secure power. If during the process you stop power, maybe compromised functionality of the unit.

1. Start software Microtec TinyBL 2.2 after install it in your machine.
2. Active codeload (connect to ground) and power on the unit.
3. Connect communication and set USB port. If communication is ok you can see in current firmware window, the version installed in your unit.
4. With button Send select and send file .mlf, give to you by Microtec.



5. Wait until after loading the firmware indicated by the hand and confirm the window pop when you see it.
6. After, remove power and disable codeload; at this point, the unit is updated and ready for use.

### **MICROTEC S.r.l.**

Sede Operativa, Via Avris 3/A – 21032 CARAVATE (VA) ITALY  
Sede Legale, Via Trieste 60/I – 21023 BESOZZO (VA) ITALY  
C.F. – P.IVA 02356120127 – Reg. Imprese 24798/1997 VA  
Tel. +39 0332 601731 – Fax +39 0332 771777